

Why pack it when you can...



Instructions-KLX450 Rack-PMB-01-2200

NOTE: We recommend using a removable thread-locking agent on all bolts.

1. Remove the eight bolts holding the black plastic tray to the rack frame.
2. Place new rack top in approximate location with the two long spacers over the fender bolt locations. (Note: the long spacers have a 7 degree taper on one side. This tapered side is to fit against the bottom of the rack top).
3. Start the two provided M6 X 50mm bolts through the long spacers but do not tighten them all the way.
4. Slide each of the shorter spacers between the new rack top and rack sides and bolt through each of these spacers with the six provided M6 x 30mm bolts but do not tighten.
5. Make sure that the taper on the long spacers fits snug against the bottom of the rack top and tighten these two bolts.
6. Tighten the remaining six bolts and periodically check all bolts for tightness.

CAUTION: As with all racks on motorcycles, they should not have excess amounts of weight put on them. Excess weight can damage the rear sub-frame of the motorcycle.

Parts List:

6-6x30 FH Bolts
2-6x50 FH Bolts
2-6x18x30 Angled Spacers
6-6x18x9 Spacers

Check out our Spark Arrestor End caps, Billet kickstands, Shark fins and other billet accessories at...

