Why pack it when you can . . .





Manufactured by: Pro Moto Billet 11461 Lone Star RD Nampa ID 83651 208-466-4762

Thank you for purchasing the best looking rack in the motorcycle industry. Your new rack is constructed of 6061 billet aluminum and then anodized to give you a high quality and good-looking rack for years of backpack free riding enjoyment.

Instructions: Yamaha 93-07 XT225 (PMB-01-5202)

NOTE: We recommend using a removable thread-locking compound on all bolts.

- 1. Remove stock grab handles (turn signals if applicable).
- 2. Install side brackets to the bike, then the grab handles, then turn signals (if applicable) using four 8x30mm hex head bolts. Leave them loose.
- 3. Install the rack top to the side brackets using four 6x16mm flat head bolts. Tighten the four rack top bolts to the side brackets.
- 4. Tighten the four side bracket/grab handle bolts.
- 5. Trim any bolts, if necessary, to provide clearance for the tire.

<u>CAUTION</u>: As with all racks on dirt bikes, they should not have excess amounts of weight put on them. Excess weight can damage the rear subframe of the motorcycle.

Parts List:

1-Top

2-Sides

4-8x30 HH

4-6x16 FH