

22-3-414 Footpeg Installation Addendum

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

2-Fastway EVO Footpegs (1-left, 1-right)
2-Footpeg Collars
1-Tall Head FKMS Bolt
1-Short Head FKMS Bolt
1-Left Spring
1-Right Spring
1-Cleat Kit (Contains enough cleats for both pegs)
4-0.040 FKMS Shims
4-0.020 FKMS Shims
2-8mm Flat Washers
1-Thread Locking Agent

NOTE: We recommend using a thread-locking agent on all bolt threads.

Before you begin:

Be sure to reference the primary “Footpeg Installation Instructions” below for peg assembly, installation, and adjustment.

Read the main instructions carefully before starting the installation. If you do not have all the required tools or are not comfortable performing the work involved, have your dealer install the footpegs for you.

The Fastway EVO footpegs for the TR650 contain two different camber bolts as well as collar washers. The following addendum explains the use of the washers to provide the best fitment for each model.

Installation notes:

1. In order for the footpegs to sit parallel to the ground, the tall head FKMS bolt should be installed in the left footpeg. The right footpeg requires the short FKMS bolt.
2. Collar washers (8mm) have also been included in order to avoid any play between the footpeg and the footpeg clevis. This washer can be installed on either side of the collar (see Figure 1, location A or B). Use only one washer per peg; make sure washer configuration is the same on both sides (choose top or bottom).

