



Instructions – PMB-01-2003

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand

1-8x25 FH

1-6x16 SH

1-M6 Washer

1-8x10x5 Spacer

1-Adapter

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Remove the lower chain roller nut, leave the factory washer installed. Install the included threaded chain roller spacer on the chain roller stud, and tighten. (*DO NOT OVER TIGHTEN!*)
2. Remove the sub-frame to main-frame mounting bolt. Install the provided sub-frame bolt spacer into the sub-frame bolt hole.
3. Install kickstand on the bike using the provided M8x30mm flat head bolt, in the upper mounting hole. Install the supplied M6x16mm socket head bolt, in the bottom mounting location.
4. Make sure that you tighten all bolts to the correct torque.
5. Periodically check the kickstand pivot bolt for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.