



## Instructions – PMB-01-2006

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

### **Parts List:**

1-Kickstand

1-10x30 SH Modified

**NOTE:** We recommend using a thread-locking agent on all bolt threads.

### **To install your new kickstand:**

1. Remove the left footpeg and footpeg bracket.
2. Install the kickstand under the left footpeg bracket using the stock bolt on the bottom and the new supplied 10x30 socket head modified bolt on the top. The kickstand base has four holes to allow the footpeg bracket to be placed in either position.
3. Make sure that you tighten the footpeg bracket bolts to the correct torque as specified in your owner's manual.
4. Re-install the footpeg.
5. Periodically check the footpeg mounting bolts, and kickstand pivot bolt for tightness.

### **To prevent damage:**

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.