



Instructions – PMB-01-5002

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand

1-8x30 FH

1-8x70 FH

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Remove the lower chain roller and bolt; make sure you keep track of the order of the small parts for re-assembly. Remove the sub-frame to main-frame bolt.
2. Install the kickstand on the bike using the 8x30mm flat head bolt. Re-Install the chain roller using the 8x70mm flat head bolt, if the bolt is too long cut it off with a hacksaw or die grinder. We recommend using a removable thread locking agent on the bolts.
3. Make sure that you tighten all bolts to the correct torque.
4. Periodically check the pivot bolt for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.