



Instructions – PMB-01-5004

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand

2-10x30 SH Modified

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Remove the left footpeg and bracket using a Torx® size T-50 wrench or socket. To ease bracket removal, use a heat gun to help loosen the factory installed thread-lock material.

NOTE: If you do not have the proper tools have your dealer install the kickstand.

2. Install the kickstand between the left footpeg bracket and the frame. Reinstall the footpeg bracket using the supplied bolts. We recommend using a removable thread-locking agent on the bolts.
3. Make sure that you tighten the footpeg bracket bolts to the correct torque as specified in your owner's manual.
4. Re-install the footpeg.
5. Periodically check the footpeg mounting bolts, and kickstand pivot bolt for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.