

Instructions – PMB-01-5009

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand
1-8x70 SH
1-M8 Washer
1-8x30 FH
1-Bracket

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Remove the lower chain roller and bolt; make sure you keep track of the order of the small parts for re-assembly. Remove the sub-frame to main-frame bolt.
2. Remove footpeg and bracket with stock kickstand.
3. Install the kickstand on the bike using the provided 8x30mm flat head bolt. Re-Install the chain roller using the provided 8x70mm socket head bolt and washer, if the bolt is too long, cut it off with a hacksaw or die grinder. We recommend using a removable thread locking agent on the bolts.
4. Install footpeg with supplied footpeg bracket and stock bolts.
5. Make sure that you tighten all bolts to the correct torque.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.