

Instructions - PMB-01-5010

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand 1-Bracket 1-M8x25 Bolt 1-M8x70 Bolt

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

- 1. Secure bike on a center stand.
- 2. Remove the stock chain guide bolt.
- 3. Install kickstand on bike by using the supplied M8x70 flat head bolt in the bottom hole of the kickstand base. The bolt will go through the base,and gain guid. Stock nut will be used on the backside of the chain guid. **NOTE**: Do not fully tighten bolt.
- 4. Install top M8x20 bolt with adjoining clamp piece.
- 5. Fully tighten bolts from steps 4 and 5.
- 6. Periodically check the kickstand leg pivot pin and all mounting bolts for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- · Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.



