

## Instructions – PMB-01-7001

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

### **Parts List:**

1-Kickstand  
1-M10x25 FHCS  
1-M10 Nylock nut

**NOTE:** We recommend using a thread-locking agent on all bolt threads.

### **To install your new kickstand:**

1. Remove the bolt attaching the stock kickstand and slide the kickstand off the frame.
2. Detach and remove the kickstand spring.
3. Slide the Fastway kickstand onto the frame and secure with the provided M10 flat-head cap crew and M10 nylock nut.
4. Periodically check all mounting bolts for tightness.

### **To prevent damage:**

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.

