

## Instructions – PMB-01-3108

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

### Parts List:

1-Spark Arrestor Base  
1-Nozzle  
1-Screen  
2-M6x55 Bolts

### Tools List:

Torx/Socket Wrenches  
Allen Wrenches

**NOTE:** Read the instructions carefully before starting the installation. If you do not have all the required tools or are not comfortable performing the work involved, have your dealer install the spark arrestor for you.

### To install your new spark arrestor:

1. Remove the two bolts holding the stock nozzle in place. **Figure 1.**
2. Pull the stock nozzle out of the canister.
3. In order to allow the inner core to align with your new spark arrestor base, loosen bolt holding the canister to the sub frame. **Figure 2.**
4. Install the spark arrestor base into the canister.
5. Insert the spark arrestor screen in the new spark arrestor base.
6. Install and tighten the spark arrestor nozzle with the supplied M6x55 bolts and stock lock washers. **Figure 3.**
7. Tighten the bolt holding the canister to the sub frame.

Figure 1



Figure 2



Figure 3



### **CAUTION:**

**You must check the condition of the spark arrestor often! Your spark arrestor will not function properly if there are holes in the screen!**

