

Instructions – PMB-01-3004

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand

1-Adapter

1-8x30 FH

1-8x25 FH

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Remove the lower chain roller and bolt making sure you keep track of the order of the small parts for re-assembly.
2. Remove the lower sub-frame to main-frame bolt.
3. Install the supplied lower kickstand mounting bracket onto the frame at the lower chain roller boss. The counter bore should slide over and onto the frame boss. The chain roller should go back into place just how it came off but with the supplied lower kickstand mounting bracket between it and the frame. Do not tighten yet, this bracket needs to pivot to align with the lower hole in the main kickstand mount.
4. Install the kickstand onto the bike using the 8x25mm flat head bolt at the sub-frame to main-frame bolt location. Do not tighten yet.
5. Line up and install the 8x30mm flat head bolt thru the lower kickstand mounting hole into the supplied lower kickstand mounting bracket.
6. Now tighten all three bolts, two main kickstand mounting bolts (front) and one lower kickstand mounting bracket bolt (rear).
7. Periodically check the kickstand leg pivot bolt and all mounting bolts for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.