

Instructions – PMB-01-3012

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand
1-Bracket
1-8x20 SH

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Remove lower sub-frame bolt. (Figure 1, Item A)
2. Re-install sub-frame bolt into upper bolt location of the kickstand. Do not tighten.
3. Install bracket into the backside of the frame, between the frame and the swing arm. (Figure 2)
4. Install the kickstand onto the bike using the 8x20mm socket head bolt through the lower bolt location and into the bracket. (Figure 1, Item B)
5. Tighten both bolts.
6. Periodically check all mounting bolts for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.

Figure 1




Figure 2

