

## Instructions: ASS-DM-0201

| ITEM # | PART NUMBER         | DESCRIPTION               | QTY. |
|--------|---------------------|---------------------------|------|
| 1      | LK-CL214            | Handlebar Riser           | 2    |
| 2      | LK-CL232            | Handlebar Top Clamp       | 2    |
| 3      | 70-2825             | Bolt M8x25                | 4    |
| 4      | VC1-10.9-M10-1.5-60 | Bolt M10x60               | 2    |
| 5      | RA6-M10.5-1.5-60    | M10 Washer                | 2    |
| 7a     | LK-SP120            | Triple Clamp Spacer 10/12 | 2    |
| 7b     | LK-SP119            | Triple Clamp Spacer 10/11 | 2    |
| 8      | LK-PL115            | Stabilizer mount          | 1    |

1. Install frame clamp using frame clamp instructions.
2. A small amount of semi-permanent thread locking fluid (Blue Loctite #243 or equivalent) should be applied to all fasteners.
3. Remove the stock handlebar risers from the triple clamp.
4. Reinstall triple-clamp, leave off stock washer between triple clamp and center nut; torque the center nut to factory specifications and then torque pinch bolts to factory specifications.
5. Place the Triple Clamp Spacers (Item 7a or 7b) in the holes on the triple clamp. Use the spacers that fit snugly into your triple clamp.
6. Set the stabilizer mount (Item 8) on the triple clamp. The open end of the mount should face the back of the bike with the slots on each end facing up.
7. Slide the M10 x 60mm bolts (Item 4) and M10 washers (Item 5) into the triple clamp from the underside.
8. Thread the handlebar risers (Item 1) onto the bolts. The handlebar risers are reversible to allow for two handlebar positions (arrows pointing forward = forward handlebar offset). Ensure that both arrows point in the same direction.
9. Tighten risers from the underside of triple-clamp. (Figure 1)
10. Place the stabilizer on the stabilizer mount. Adjust the height of the tower pin so that the top of the pin is flush with the top of the transfer arm. **See frame clamp instructions for details.** (Figure 2)
11. Insert the tower pin into the slot on the transfer arm and attach the stabilizer to the stabilizer mount using the two M6 bolts included with the stabilizer.
12. Install handlebars and top clamps (Item 2) using the M8 x 25mm bolts (Item 3). Make sure to maintain an even gap between the handlebar top clamps and the handlebar risers when tightening bolts. (Figure 3)




Figure 1



Figure 2



Figure 3

See our entire product line at [promotobillet.com](http://promotobillet.com)